

DuPont™ Vespel®

Rotating Equipment Reliability Technology

VESPEL® CR-6100 BEARINGS FOR API (AMERICAN PETROLEUM INSTITUTE) SEPARATORS



API Separator

The API separator is equipment typically found in oil refineries. It handles foul water from refinery process sewers and sends its to the treatment plant for processing. It also sends oil back to the coker or for other reprocessing. This service contains hydrocarbons, water, acids, particles, amines and ammonia.

Challenge

Sleeve bearings support series of 21 foot (6.4m) long shafts in the 4 inch (101.6mm) diameter range. Unit size determines the number of shafts and some units are hundreds of feet long. The bearings drive skimmers and are historically babbitt or bronze. Greased bushings fail due to corrosion and contamination. Nicker-graphite bushings wear and score the shafts.

Solution

DuPont™ Vespel® CR-6100 bearings increase performance and reliability and reduce failures to extend life and lower maintenance costs. Vespel® CR-6100 can operate without lubrication because of its low wear and low coefficient friction. The composite nature of Vespel® CR-6100 allows for less damage to the shaft at contact which extends the life of the equipment. In addition, its chemical resistance allows for operation in the most diverse aggressive services.



System Shafts



Bronze Bushing



Metal impregnated graphite
3.5 year service
0.5" (12.7mm)
Wear, shaft damage
Not serviceable

Vespel® CR-6100
3.5 year service
0.02" (0.51mm) Wear, no shaft damage
Serviceable

For technical support,
material samples, or
a machining guide, call
1-800-222-VESP (8377)
www.vespel.dupont.com

Comparative Wear Data								
Material	Wear Rate (E-6)				Dynamic Coefficient of Friction		Limiting PV	
	25 ft./min. (0.13m/sec.)		50 ft./min. (0.25m/sec.)		25 ft./min. (0.13 m/sec.)	50 ft./min. (0.25 m/sec.)	English (psi-ft./min)	SI Units (MPa-m/sec.)
	in./hr.	cm/hr.	in./hr.	cm/hr.				
Vespel® CR-6100	27.1	68.8	74.4	189.0	0.20	0.29	>155,000	>5.4
Carbon Fiber/PFA	47.1	119.6	102.8	261.1	0.18	0.24	>92,000	>3.2
PEEK-Lubricated	70.7	179.6	149.2*	379.0	0.52	0.18	40,000	1.4
PAI-Lubricated, Wear-resistant	37.3	94.7	1,435.2*	3,645.4	0.33	0.21	64,000	2.2
Carbon Fiber/PEEK	85.2	216.4	—	—	0.29	—	—	—
Glass Fiber/PEEK	93.2	236.7	—	—	0.26	—	—	—
PEEK (Unfilled)	699.0	1,775.5	—	—	0.42	—	—	—

*Stick-slip, vibration.
Unlubricated pin on AISI carbon steel disc finished to 16 microinches (0.4 micrometers) (AA): 400 psi (8.9 MPa)



The miracles of science™

Broad Chemical Resistance*

Acids	Vespel® CR-6100	PEEK
Aqua Regia	A	C
Chromic Acid>50%	A	D
Chlorosulfonic Acid	A	D
Sulfuric Acid, 96%	A	D
Phosphoric Acid, 85%	A	B
Fluoboric Acid	A	D
Fluorosilicic Acid	A	D
Hydrofluosilicic Acid	A	D
Nitric Acid	A	D
Solvents		
Acetone	A	C
Ketones	A	C
Tetrahydrofuran	A	N/A
Methyl Acetone	A	C
Methyl Ethyl Ketone	A	C
Methyl Isobutyle Ketone	A	C
Dimethyl Sulfoxide	A	N/A
Oleum	A	D
Other		
Bromine	A	C
Sodium Hydroxide	A	C
Aq Zinc Chloride, 25%	A	N/A
Caustic Soda	A	C
Caustic potash	A	C
Chlorinated Water	A	D
Oxygen	A	D
Steam	A	A
Iodine	A	D
Oleum	A	D

Explanation of Ratings

A = Excellent, B = Good, C = Poor, D = Do not use

* Source: Chemical Resistance Guide for Plastics. Compass Publication

DuPont™ Vespel® CR-6100 parts and shapes are polymeric composite articles consisting of PFA/CF reinforced composite, 20 % mass fraction random X-Y oriented carbon-fibre.

Phone: 800-222-VESP (8377)

Fax: 302-999-2311

E-mail: web-inquiries.DDF@usa.dupont.com

Web: vespel.dupont.com

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable. It is intended for use by persons having technical skill, at their own discretion and risk. This information corresponds to our current knowledge on the subject. It is offered solely to provide possible suggestions for your own experimentation. It is not intended, however, to substitute for any testing you may need to conduct to determine for yourself the suitability of our products for your particular purposes. The data listed herein falls within the normal range of product properties but they should not be used to establish specification limits or used alone as the basis of design. This information may be subject to revision as new knowledge and experience becomes available. Since we cannot anticipate all variations in actual end-use conditions, DuPont makes no warranties and assumes no liability in connection with any use of this information. Nothing in this publication is to be considered as a license to operate under or a recommendation to infringe any patent right.

Caution: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, see "DuPont Medical Caution Statement," H-50102.

Copyright © 2009 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, and Vespel® are registered trademarks or trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved.

K-22692 (11/20/09 rev-3) Printed in the U.S.A.



The miracles of science™